

USER MANUAL

WC60DD series





Thanks for choosing our products, hope that our products can bring you different feelings. Please read the following safety and operating instructions carefully before using the wine cooler.

WINE CHILLER SAFETY

Your safety and the safety of others are very important.

We have provided many important safety messages in this manual and on your appliance. Always read and obey all safety messages.



This is the Safety Alert Symbol. This symbol alerts you to potential hazards that can kill or injure you and others. All safety messages will follow the Safety Alert Symbol and either the words "DANGER", "WARNING" or "CAUTION".



Danger means that failure to heed this safety statement may result in severe personal injury or death.



Warning means that failure to heed this safety statement may result in extensive product damage, serious personal injury, or death.

CAUTION

Caution means that failure to heed this safety statement may result in minor or moderate personal injury, or property or equipment damage.

All safety messages will alert you do what the potential hazard is, tell you how to reduce the chance of injury, and let you know what can happen if the instructions are not followed.

IMPORTANT SAFEGUIDES



Before the appliance is used, it must be properly positioned and installed as described in this manual, so read the manual carefully. To reduce the risk of fire, electrical shock or injury when using the appliance, follow basic precaution, including the following:

A DANGER A

- Plug into a grounded 3-prong outlet, do not remove grounding prong, do not use an adapter, and do not use an extension cord.
- Replace all panels before operating.
- It is recommended that a separate circuit, serving only your appliance be provided. Use receptacles that cannot be turned off by a switch or pull chain.
- Never clean appliance parts with flammable fluids. These fumes can create a fire hazard or explosion.
 And do not store or use gasoline or other flammable vapours and liquids in the vicinity of this or any other appliance. The fumes can create a fire hazard or explosion.
- Before proceeding with cleaning and maintenance operations, make sure the power line of the unit is disconnected.
- Do not connect or disconnect the electric plug when your hands are wet.
- Unplug the appliance or disconnect power before cleaning or servicing. Failure to do so can result in electrical shock or death.
- Do not attempt to repair or replace any part of your appliance unless it is specifically recommended in this material. All other servicing should be referred to a qualified technician.



- Use two or more people to move and install appliance. Failure to do so can result in back or other injury. To ensure proper ventilation for your appliance, the front of the unit must be completely unobstructed. Choose a well-ventilated area with temperatures above 16°C (60°F) and below 32°C (90°F). This unit must be installed in an area protected from the element, such as wind, rain, water spray or drips.
- The appliance should not be located next to ovens, grills or other sources of high heat.
- The appliance must be installed with all electrical, water and drain connections in accordance with state and local codes. A standard electrical supply (220V/50Hz), properly grounded in accordance with the National Electrical Code and local codes and ordinances is required.
- Do not kink or pinch the power supply cord of appliance.
- The fuse (or circuit breaker) size should be 13 amperes.
- It is important for the appliance to be leveled in order to work properly. You may need to make several adjustments to level it.
- Never allow children to operate, play with or crawl inside the appliance.
- Do not use solvent-based cleaning agents of abrasives on the interior. These cleaners may damage or discolor the interior.
- Do not use this apparatus for other than its intended purpose.

↑ FLAMMABLE REFRIGERANT GAS ↑

DANGER - Risk of fire or explosion. Flammable refrigerant used.

DO NOT use mechanical devices to defrost refrigerator. DO NOT puncture refrigerant tubing.

DANGER - Risk of fire or explosion. Flammable refrigerant used. To be repaired only by trained service personnel. DO NOT puncture refrigerant tubing.

CAUTION - Risk of fire or explosion. Flammable refrigerant used. Consult repair manual / owner's guide before attempting to service this product. All safety precautions must be followed.

CAUTION - Risk of fire or explosion. Dispose of property in accordance with federal or local regulations. Flammable refrigerant used.

CAUTION - Risk of fire or explosion due to puncture of refrigerant tubing. Follow handling instructions carefully. Flammable refrigerant used.

CAUTION - To prevent a child from being entrapped, keep out of reach of children and not in the vicinity of the cooler.

IMPORTANT SAFETY INSTRUCTIONS

₩WARNING

To reduce the risk of fire, electrical shock, or injury when using your appliance, follow these basic precautions:


- Read all instructions before using the wine chiller.
- DANGER or WARNING: Risk of child entrapment.
 - Child entrapment and suffocation are not problems of the past. Junked or abandoned appliances are still dangerous.
- Before you throw away your old wine chiller, take off the door but leave the shelves in place so that children may not easily climb inside.
- Never allow children to operate, play with, or crawl inside the appliance.
- Never clean appliance parts with flammable fluids. The fumes can create a fire hazard or explosion.
- Do not store or use gasoline or any other flammable vapours and liquids in the vicinity of this
 or any other appliance. The fumes can create a fire hazard or explosion.

-Save these instructions-

OPERATION AND TEMPERATURE SETTING

This wine cooler is suitable for the ambient temperature 5-32°C. If temperature is higher or lower than it, the performance may be affected.

Temperature setting




- ①LED ON/OFF;
- ②Temperature up (Press it, temperature will go up 1 degree);
- ③Display window;
- (4) Fahrenheit and Celsius indicate light;
- ⑤Temperature down (Press it, temperature will decrease 1 degree);
- (6) Fahrenheit & Celsius switch button;
- ⑦Power ON/OFF: Press"POWER"button for 3 seconds to turn off the appliance. Press it to turn on it

WARNING:

- If the appliance is power off suddenly. Please turn on the appliance after 3-5 minutes later. The temperature setting is with automatic memory function.
- If it is the first time to use this appliance, it is normal that the preset temperature and display temperature is different. Everything will back to normal after few hours working.

<u>Shelf</u>


- To avoid the damage of door sealing, please open the door fully when you slide out the shelves.
- For your convenience of taking wine, you can pull out the shelf by 1/3. Our product is designed with shelf holder to prevent the shelf pull over and fall off the cabinet.
- If need to take off the shelf from cabinet, you can pull out the shelf to the shelf holder position, then lift up the shelf to remove the shelf. (See figure below)



Reverse the door

The door is reversible. The default way to open the door is left opening. If need to reverse the door, do as the following figures shows

YC120-2D:




A: Glass door B: Hexagonal wrench


Procedure to reverse the door:

- 1. Fig:1, remove the screws on lower hinge by hexagonal wrench. Please hold the door to avoid the door drop down after loosing of screws.
- 2. Fig:2 Remove the door in position ①, then take out the door in position ②. Fig:3 shows the door is taken out:
- 3. Fig:4 Tilt the door and insert to the top like ① shows, then move the door levelly to make it in the same level with the cabinet (③)Fig:5, before tighten the bottom screws, to make sure the door is in the same level with
- 4. The 62 bill reverse is finished;

Built-in installation drawing YC120-2D



Door handle installation



(4)Handle 1) sealing 2screws 3 Phillips screwdriver

How to install the handle:

- 1) Pull away the door gasket in the area where the handle is to be installed on the left side as shown below in Fig1. The gasket is easily displaced by hand, no tools are necessary.
- 2) Align the handle with the screws installed. Tighten the screws using a Phillips head screwdriver until the handle sets both flush and secured tightly against the door frame. (DO NOT over tighten as this will cause damage to the handle assembly).
- 3) Replace the door gasket to its original position.

Care and Maintenance

- Cleaning your wine cooler
- Turn off the power, unplug the appliance, and remove all items including shelves
- Wash the inside surfaces with a warm water and soft cloth
- Wash the shelves with a mild detergent solution
- Wring excess water out of the sponge or cloth when cleaning area of the controls, or any electrical parts
- Wash the outside cabinet with warm water and mild liquid detergent. Rinse well and wipe dry with a clean soft cloth. Do not use steel wool or steel brush on the stainless steel. These will contaminate the stainless steel with steel particles and rusting may occur.

Power failure

Most power failures are corrected within a few hours and should not affect the temperature of your appliance if you minimize the number of times the door is opened. If the power is going to be off for a longer period of time, you need to take the proper steps to protect your contents.

Moving your wine chiller

-Remove all items (bottles)

- -Tape down securely all loose items (shelves) inside your appliance.
- -Turn the adjustable leg up to the base to avoid damage.
- -Tape the door shut. Be sure the appliance stays secure in the upright position during transportation. If you absolutely need to transport the chiller horizontally, transport the chiller on its back (door on top). Also protect outside of appliance with a blanket, or similar item.

Energy saving tips

The wine chiller should be located in the coolest area of the room, away from heat producing appliances, and out of the direct sunlight.

TROUBLESHOOTING GUIDE

You can solve many common wine chiller problems easily, saving you the cost of a possible service call. Try the suggestions below to see if you can solve the problem before calling the service.

Troubleshooting guide

| PROBLEM | POSSIBLE CAUSE |
|---|---|
| Wine cooler does not operate. | Not plugged in. The appliance is turned off. The circuit breaker tripped or a blown fuse. |
| Wine cooler is not cold enough. | External environment may require a higher setting. The door is opened too often. The door is not closed completely. The door gasket does not seal properly. |
| The compressor turns on and off frequently. | The room temperature is hotter than normal. A lots of bottles has been added to the chiller. The door is opened too often. The door is not closed completely. The temperature control is not set correctly. The door gasket does not seal properly. |
| The light does not work | Not plugged in. The circuit breaker tripped or a blown fuse. The light button is "OFF". |
| Vibrations. | The chiller is not leveled The bottles are vibrating. There is an object under the chiller. |
| The chiller seems to make too much noise. | The flow of refrigerant is normal The circulation of the refrigeration The chiller is not level. |
| The door will not close properly. | The chiller is not level. The door was reversed and not properly installed. The gasket is dirty. The shelves are out of position. |